
ΗΙΟΚΙ

SWITCH MAINFRAME SW1001, SW1002



Packed with Features to Ensure Accuracy in Battery Measurements

- O Circuit design friendly for impedance measurements that minimize errors between channels (Effect: 0.01% f.s.*)
- O For OCV measurement, internal resistance measurement, and external potential measurement of battery cells
- O Measure battery modules up to 60 V DC
- O Switch between voltmeter and battery tester while testing
- O Built-in short-circuit protection fuse for each channel



Multi-channel Battery Testing

Combine the SW1001 or SW1002 with a battery testing instrument to measure a battery cell's OCV (open circuit voltage), internal resistance, reaction resistance at low frequency, Cole-Cole plot, and external potential on multiple channels.

SW1001




3 Slots 2-wire: 66 channels; 4-wire: 33 channels; 4-terminal pair: 18 channels (Max. number of channels)

SW1002



12 Slots 2-wire: 264 channels; 4-wire: 132 channels; 4-terminal pair: 72 channels (Max. number of channels)



Connect Up to Two Measuring Instruments with Different Functions

Switch between two types of measuring instruments to perform a variety of measurements.*

Switch between PRECISION DC VOLTMETER DM7276 and BATTERY IMPEDANCE Configuration Example METER BT4560 SW1002 20.000 -0 0 0 DM7276 BT4560 Cell OCV measurements Cell internal resistance measurements External potential measurements Cole-Cole plot measurements between electrode and case * One 2-wire module and one 4-wire module or 4-terminal pair (BNC) module can be used together (see page 7). Only one channel can be measured at a time. Two modules cannot be used at the same time to measure multiple channels.

Battery Measurement Supported by Exclusive PC Application

Use the free, downloadable PC application to perform various measurements easily.*

OCV Measurement function SW1001Appli - Basic m e(M) Set(S) Tools(T) Language(L) Help(H) File(F) Mo dV/Last 1hr v V 1st data dV сн [v] [mV] [mV/day] [mV/hr] [V] 3 782930 -0.015 1 +03 782915E+00 -1201-28.7992 +03.782915E+00 3.782932 -0.017 -32.638 -1.361


Logging function

CH1:	CH2:	CH3:	. Single mossurement
R 1.3202E-003 Ω	R 1.3137E-003 Ω	R 1.3171E-003 Ω	D-Start =
V 3.73378E+000 V	V 3.72299E+000 V	V 3.72855E+000 V	
CH4:	CH5:	CH6:	Test Vacuated rates
R 1.2819E-003 Ω	R 1.3139E-003 Ω	R 1.2788E-003 Ω	
V 3.66999E+000 V	V 3.72332E+000 V	V 3.66476E+000 V	
CH7:	CH8:	CH9:	Olive actual V-table
R 1.2821E-003 Ω	R 1.2757E-003 Ω	R 1.2790E-003 Ω	
V 3.67032E+000 V	V 3.65953E+000 V	V 3.66509E+000 V	
CH10:	CH11:	CH12:	Start =
R 1.2725E-003 Ω	R 1.2759E-003 Ω	R 1.3294E-003 Ω	
V 3.65429E+000 V	V 3.65986E+000 V	V 3.74906E+000 V	
CH13:	CH14:	CH15:	II *****
R 1.2727E-003 Ω	R 1.2976E-003 Ω	R 1.3296E-003 Ω	Interval: Nosc
V 3.65462E+000 V	V 3.69607E+000 V	V 3.74939E+000 V	Gaunt:
CH16:	CH17:	CH18:	Start:
R 1.2945E-003 Ω	R 1.2978E-003 Ω	R 1.2913E-003 Ω	
V 3.69083E+000 V	V 3.69640E+000 V	V 3.68560E+000 V	
CH19:	CH20:	CH21:	Digoed Time:
R 1.2947E-003 Ω	R 1.2882E-003 Ω	R 1.2915E-003 Ω	
V 3.69116E+000 V	V 3.68037E+000 V	V 3.68593E+000 V	
CH22: R 1.2850E-003 Ω V 3.67513E+000 V			Distar 0
Model: SW1881 B	tudet: 971552	Measurement CH Start: 1 End: 22	STOPPED

Use in combination with supported measurement instruments to perform logging measurements (Interval setting: 1 second to 60 minutes) for up to 264 channels. The judgment function makes it easy to determine the channel on which an abnormality occurred.

Enjoy basic functions as well as a newly added dedicated OCV measurement function. This allows you to measure initial voltage, voltage drops, voltage drop rate (mV/day), and the latest voltage drop rate (mV/hour) in addition to OCV measurement values.

A judgment function is also included, making it easy to determine which battery cell is experiencing aging defects.



Use in combination with the BT4560 or the IM3590 to perform multi-channel Cole-Cole plot measurements. Allows testing to be performed efficiently for R&D and quality assurance.

*Supported measuring instruments: DM7275, DM7276, BT3562, BT3563, 3561, BT4560, IM3590, RM3545, RM3544-01 *Save measurement data in CSV file format. Create save files for each channel. IRS-232C/USB/LAN supported (matching the communication function of the connected device).

LabVIEW[®] Compatibility

Build a measurement system with your LabVIEW® software and our LabVIEW® driver.*


Download the LabVIEW® driver from the HIOKI website at www. hioki.com.

*LabVIEW® is a trademark of National Instruments Corporation.


HIOKI products compatible with LabVIEW drivers (As of October 2019)						
SW1001, SW1002	OK	DM7275, DM7276	OK			
BT3562, BT3563	OK	3561	NG			
BT4560	OK	IM3590	OK			
RM3545	OK	RM3544-01	OK			

Circuit Design for Impedance Measurements

The effect on the detection signal is reduced by canceling the magnetic flux of the AC measurement current and separating the source from the sense.



With the 4-terminal method, magnetic flux is generated from the AC measurement current. Further, the magnetic flux generates an eddy current in the surrounding metal, and the magnetic flux from that eddy current affects the detection signal, resulting in errors in measurement values.



Error in Measurement Values between Channels/Slots Due to Use of Switching System

Example of measurement with BT3562

Measurement conditions: $3 \text{ m}\Omega$ range, 0Ω measurement, after zero adjustment by direct connection




From the measurement results ...

Example of measurement with BT4560

Measurement conditions: RX function, 3 mΩ range, 1 kHz, 0 Ω measurement, after zero adjustment by direct connection






Little error between when a switch is used or not used. (direct connection of measurement instrument) Little error between channels. Little error between slots.

Reliable measurement with little effect from eddy currents

Example of Connection Cables and Supported Measurement Instruments



Choose from Two Types of Multiplexer Modules

MULTIPLEXER MODULE SW9001

This module supports 2-wire/4-wire configurations. Channel switching can be performed in 11 ms (excluding communication, command processing time, and contact bounce).



Wiring Method	No. of Channels	I Туре	Used Signals			
2-wire	22	Sei	nse	CH 1 to CH 22		
4-wire	11	irce	CH 1 to CH 11			
4-wire		Sei	nse	CH 12 to CH 22		
	connected Meas struments	uring	Ter	minal	Connection Cable	
PRECISION DO	VOLTMETER D	DM7276	TERMINAL 1		L4930	
BATTERY	62	TERM	/INAL 2	L2108		

MULTIPLEXER MODULE SW9002

This module supports 4-terminal pair configuration for use in combination with BT4560 and IM3590. 2-wire measurement is also possible (Sense only). Channel switching can be performed in 11 ms (excluding communication, command processing time, and contact bounce).



Wiring Method	No. of Channels	Signa	Signal Type Used Signa		d Signals	
2-wire	6	Sei	nse	Sense (CH 1 to CH 6	
		Sou	irce	Source CH 1 to CH 6		
4-terminal pair	6	Ret	urn	Return CH 1 to CH 6		
		Sei	nse	Sense (CH 1 to CH 6	
Example of Co In	rement	Ter	rminal	Connection Cable		
PRECISION DO	VOLTMETER D	DM7276	TERN	/INAL 1	L4930	
BATTERY IMPE	DANCE METER I	BT4560	TERN	/INAL 3	L2004	

Examples of Switching Measurement Time (Use in combination with SW1002 to measure the actual time for scan measurements.)*

* Communication with SW1002 via USB.

Module	Measuring Instrument	Function	Measurement Speed	No. of Channels	Delay Time	Scan Time (All Channels)	Conditions		
					0.02 PLC	22	0 ms	0.45 s (Approx. 20 ms/CH)	Communication with DM7276 via USB
	DM7276	V	FAST	22	0 ms	0.85 s (Approx. 39 ms/CH)	Contact check OFF		
SW9001			MEDIUM	22	0 ms	4.9 s (Approx. 223 ms/CH)	Contact check of t		
	BT3562	ΩV	EX. FAST	11	10 ms	0.45 s (Approx. 41 ms/CH)	Communication with BT3562		
	D13302	12 V	MEDIUM	11	10 ms	1.1 s (Approx. 100 ms/CH)	via RS-232C (38,400 bps)		
			FAST	6	0 ms	1.0 s (Approx. 167 ms/CH)	Communication with BT4560 via USB		
SW9002	BT4560	RX	MEDIUM	6	0 ms	1.2 s (Approx. 200 ms/CH)	(9600 bps) Measurement frequency: 1 kHz		

Control Interface/Useful Functions

Channel switching is controlled by the communication interface. LAN/USB/RS-232C interfaces are supported.

Rear Interfaces



Communication I/F: LAN/USB/RS-232C (HOST) Transmission of communication commands to measurement instruments: RS-232C (INSTRUMENT) For scanner control: EXT. I/O^{*1}

EXT. I/O Signal Table


	0			
Pin	Signal Name	I/O	Function	Logic
1	SCAN	IN	Start/advance scan	Edge
2	(Reserved)	IN	-	-
3	ISO_5V	-	Isolated power +5 V (-5 V) output	-
4	CLOSE	OUT	Complete channel closing	Pulse
5	(Reserved)	OUT	-	-
6	SCAN RESET	IN	Reset scan operation	Edge
7	(Reserved)	IN	-	-
8	ISO_COM	-	Isolated power common	-
9	(Reserved)	OUT	-	-

*1 9-pin D-sub (Female #4-40 screw), Input: Photocoupler isolated non-voltage contact input, Output: Photocoupler isolated open drain output

Communication Command Transmission Function Reduces the Number of PC Ports Needed

Normally, PC control requires two ports: one communication port for switching and one for the measuring instrument. By using the communication command transmission function on the SW1001 and SW1002, the switch mainframe can transfer control commands from the PC to the measuring instrument (and responses can be received from the device). This allows you to reduce the number of communication ports used on the measuring instrument.^{*2}

*2 The measuring instrument is connected with the RS-232C. Only one instrument is supported (one port).



Control Command Transmission from PC

Command transfered to Measuring Instrument

Scan Function

This function switches between channels in order based on the scan list registered in advance.

The switch mainframe and the EXT. I/O of the measuring instrument are connected. With the scan function, channel switching and trigger measurement can be synced for continuous scanning. *3

*3 To obtain the measurement value, use the data output function or the memory function on the measuring instruments.



Use the PC App

Relay Open/Close Count Function

The number of times each relay opens/ closes can be confirmed on the PC application. This allows you to estimate the service life of a relay.

Module	Model	Serial No.	Version	Relay(max)	Relay1	Relay2	Relay3	Relay4	Relay5	Relay6	Re
MAINFLAME	SW1002	180610765	V1.00								
SLOT1	SW9001	180610772		57	57	57	57	57	57	57	52
SLOT2	SW9002	180610773		31	29	28	27	27	27	27	0
SLOT3	-										
SLOT4	-										
SLOT5	-										
SLOT6	_										

Connector Pin Layout for Measurement of Multiplexer Module

50-pin D-sub	SW9	001 Co	onr	iectoi	r signa	al ta	able		
(Male #4-40 screw UNC)	Pin	Signa	al	Pin	Signa	ıl	Pin	Signa	ιI
	17	Shiel	d	33	CH11	н	50	CH11	L
$\begin{pmatrix} 17 \\ 0 33 \\ 0 \end{pmatrix}$	16	CH10	Н	32	CH9	L	49	CH10	L
	15	CH9	Н	31	CH8	Н	48	CH8	L
	14	CH7	Н	30	CH6	L	47	CH7	L
0 0 0	13	CH6	Н	29	CH5	Н	46	CH5	L
	12	CH4	Н	28	CH3	L	45	CH4	L
	11	СНЗ	Н	27	CH2	Н	44	CH2	L
	10	CH1	Н	26	Shield	b	43	CH1	L
	9	Shiel	b	25	CH22	Н	42	CH22	L
	8	CH21	Н	24	CH20	L	41	CH21	L
	7	CH20	Н	23	CH19	Н	40	CH19	L
0 0	6	CH18	Н	22	CH17	L	39	CH18	L
0 0 0	5	CH17	Н	21	CH16	Н	38	CH16	L
	4	CH15	Н	20	CH14	L	37	CH15	L
	3	CH14	Н	19	CH13	Н	36	CH13	L
	2	CH12	Н	18	Shield	b	35	CH12	L
0 18 0 1 34	1	Shiel	b	-	-		34	Shield	k
	ith a 4-wi	re system	char	nel n an	d channel	n+11	are Sou	irce/Sense	- nair

SW9002 Connector signal table

37-pin D-sub	n D-sub SW9002 Connector signal table							
(Male #4-40 screw UNC)	Pin	S	ignal		Pin	Sig	gnal	
(19	19	Return	CH6	L	37	Source	CH6	L
	18	Return	CH5	L	36	Source	CH5	L
	17	Return	CH4	L	35	Source	CH4	L
0 0	16	Return	CH3	L	34	Source	СНЗ	L
	15	Return	CH2	L	33	Source	CH2	L
	14	Return	CH1	L	32	Source	CH1	L
	13	Source	CH1	Н	31	Return	CH1	Н
0 0	12	Source	CH2	Н	30	Return	CH2	Н
	11	Source	CH3	Н	29	Return	СНЗ	Н
	10	Source	CH4	Н	28	Return	CH4	Н
	9	Source	CH5	Н	27	Return	CH5	Н
	8	Source	CH6	Н	26	Return	CH6	Н
	7	S	hield		25	Sense	CH1	L
	6	Sense	CH1	Н	24	Sense	CH2	L
	5	Sense	CH2	Н	23	Sense	СНЗ	L
0 0	4	Sense	CH3	Н	22	Sense	CH4	L
	3	Sense	CH4	Н	21	Sense	CH5	L
	2	Sense	CH5	Н	20	Sense	CH6	L
	1	Sense	CH6	Н				

With a 4-wire system, channel n and channel n+11 are Source/Sense pairs.

Please prepare measurement cables (multiplexer module - measurement target). Connectors For SW9001: DD-50SF-N, For SW9002: DC-37SF-N (Manufactured by Japan Aviation Electronics Industry, Ltd.) When a 2-wire system is used, only Sense CH1 to CH6 are enabled.

Effects when Used in Combination with a Measurement Instrument

Combined measurement accuracy = Accuracy of measurement instrument + Combined effects

SW9001

(

BT3562, BT3563	BT3562, BT3563 (connected with L2108)							
Range	Effect	Conditions and Remarks						
R 3 mΩ	±0.1% f.s.	-						
R 30 mΩ to 300 Ω	±0.03% f.s.	-						
R 3000 Ω *1 ±3.0% rdg. ±0.03% f.s.		Measurement abnormality detection not possible						
Entire V range	±5 µV *2	After stabilization of temperature in usage environment Within 1 minute of contact closing						

3561 (connected with L2108)							
Range	Effect	Conditions and Remarks					
Entire R range	±0.03% f.s.	-					
Entire V range	±5 µV *2	After stabilization of temperature in usage environment Within 1 minute of contact closing					

DM7275, DM7276	DM7275, DM7276 (connected with L4930)						
Range	Effect	Conditions and Remarks					
Entire V range	$\pm7~\mu V$ *2	After stabilization of temperature in usage environment Within 1 minute of contact closing					

List of possible combinations when using two measuring instruments together

One 2-wire module + one 4-wire module, or one 2-wire module + one 4-terminal pair module can be used together.

1st Module	2nd Module
	BT3562 or 3561
DM7275 or DM7276	BT4560
	IM3590

Combinations of two 2-wire modules, two 4-wire modules, or one 4-wire module + one 4-terminal pair module are not possible.

SW9002	

2002			
BT4560 (connected with L2004)			
	Effect		
Range	Freq. Range 0.1 Hz to 100 Hz	Freq. Range 110 Hz to 1050 Hz	Conditions and Remarks
3 mΩ R	±0.05% f.s.	±0.1% f.s.	-
3 mΩ X	±0.1% f.s.	±1.0% f.s.	-
10 mΩ R	±0.015% f.s.	±0.03% f.s.	-
10 mΩ X	±0.03% f.s.	±0.3% f.s.	-
100 mΩ R	±0.01% f.s.	±0.01% f.s.	-
100 mΩ X	±0.015% f.s.	±0.03% f.s.	-
Entire V range	±5 µV *2		After stabilization of temperature in usage environment Within 1 minute of contact closing

IM3590 *3 (connected with L2004)		
Range	Effect	Conditions and Remarks
100 mΩ to 10 Ω	IM3590 measurement accuracy ×1	DC, 0.001 Hz to 10.000 kHz
100 Ω to 10 kΩ	IM3590 measurement accuracy ×3	DC, 0.001 Hz to 10.000 kHz Impedance upper limit 10 k Ω
DM7275, DM7276 (c	onnected with L4930)	
Range	Effect	Conditions and Remarks
Entire V range	±7 μV *2	After stabilization of temperature in usage environment Within 1 minute of contact closing

*1 Measurement anomaly detection function not available in the 3000 Ω range of the BT3562 and BT3563.

*2 The effect of voltage measurement includes the offset voltage of the basic specifications.

*3 The effect when used in combination with the IM3590 is a reference value. It is not a guaranteed value.

SWITCH MAINFRAME SW1001. SWITCH MAINFRAME SW1002 Specifications *1

Slots	3 slots (SW1001), 12 slots (SW1002)	Functions	Channel switching, wiring method, scan function, communication command transmission, channel delay, shield switching
Supported modules MULTIPLEXER MODULE SW9001 (2-wire/4-wire) MULTIPLEXER MODULE SW9002 (4-terminal pair)	MULTIPLEVER MODULE SW0001 (2 mino/4 mino)		
	Display	Power LED, Error LED, Remote LED	
	Compliance standards	Safety: EN61010, EMC: EN61326 Class A	
Connectible instruments	Max. 2 units 2-wire x 1 + 4-wire x 1, or 2-wire x 1 + 4-terminal pair x 1	Operating temperature and humidity range	0°C to 40°C (32°F to 104°F), 80% RH or less (no condensation)
Analog bus terminal TERMINAL 1: Banana terminal (2-wire) TERMINAL 2: Banana terminal (4-wire) TERMINAL 3: BNC terminal (4-terminal pair)	Storage temperature and humidity range	-10°C to 50°C (14°F to 122°F), 80% RH or less (no condensation)	
	Operating environment	Indoors, Pollution Degree 2, altitude up to 2000 m (6562.20 ft)	
	Power supply	100 to 240 V AC / 30 VA (50/60 Hz)	
Maximum input voltage	60 V DC *2, 30 V AC rms, 42.4 V peak	Dimensions and mass	Approx. 215 mm (8.46 in) W x 132 mm (5.20 in) H x 420 mm (16.54 in) D, Approx. 3.7 kg (130.5 oz) (SW1001) Approx. 430 mm (16.93 in) W x 132 mm (5.20 in) H x 420 mm (16.54 in) D,
Maximum rated voltage to ground	60 V DC		
Communication I/F	LAN, USB, RS-232C (for host, for measurement instruments)		Approx. 6.0 kg (211.6 oz) (SW1002) Power cord x 1, instruction manual x 1, usage precautions x 1, USB driver CD x 1
EXT. I/O	SCAN input, SCAN_RESET input, CLOSE output (to control scanner)	Accessories	

MULTIPLEXER MODULE SW9001 Specifications^{*1}

Wiring method	2-wire or 4-wire
No. of channels	22 channels (2-wire) / 11 channels (4-wire)
Contact method	Armature relays
Channel switching time	11 ms (excluding measurement time)
Max. allowable voltage	60 V DC, 30 V AC rms, 42.4 V peak
Max. allowable current	1 A DC, 1 A AC rms
Max. allowable power	30 W (resistive load)
Maximum rated voltage to ground	60 V DC
Offset voltage *3	5 µV (TERMINAL 1, TERMINAL 2 Sense)
Initial path resistance	Less than 1.5 Ω (when using TERMINAL 1) Less than 0.7 Ω (when using TERMINAL 2, 3)
Insulation resistance	1 G Ω or more between High-Low channels (at 60 V DC)
Contact life (reference value)	No load: 50 million times 30 V capacitive load (1.2 μF + 60 Ω, 500 mA peak): 10 million times
Dimensions and mass	Approx. 25.5 mm (1.00 in) W x 110 mm (4.33 in) H x 257 mm (10.12 in) D, Approx. 210 g (7.4 oz)
Accessories	Instruction manual x 1

MULTIPLEXER MODULE SW9002 Specifications*1

Wiring method	4-terminal pair (6-wire) or 2-wire
No. of channels	6 channels (4-terminal pair) / 6 channels (2-wire)
Contact method	Armature relays
Channel switching time	11 ms (excluding measurement time)
Max. allowable voltage	60 V DC, 30 V AC rms, 42.4 V peak
Max. allowable current	1 A DC, 1 A AC rms (Sense) 2 A DC, 2 A AC rms (Source, Return)
Max. allowable power	30 W (resistive load)
Maximum rated voltage to ground	60 V DC
Offset voltage *3	5 µV (TERMINAL 1, TERMINAL 2 Sense)
Initial path resistance	Less than 1.5 Ω (when using TERMINAL 1) Less than 1.0 Ω (when using TERMINAL 2, 3)
Insulation resistance	1 GΩ or more between High-Low channels (at 60 V DC)
Contact life (reference value)	No load: 50 million times
Dimensions and mass	Approx. 25.5 mm (1.00 in) W x 110 mm (4.33 in) H x 257 mm (10.12 in) D, Approx. 196 g (6.9 oz)
Accessories	Instruction manual x 1

*1 Product warranty period: 3 years (excluding relays and fuses)

*2 Cannot connect to battery packs in excess of 60 V DC.

info@asm-sensor.de

www.asm-sensor.de

*3 The offset value is from within 1 minute of closing the channel. This value is also taken when the temperature of the usage environment is sufficiently stable, and when the instrument has acclimated to that temperature

Lineup



Model No. (Order Code) : SW1001



Model No. (Order Code) : SW1002

Module not included with the switch mainframe. Modules must be purchased separately.

Optional Modules



MULTIPLEXER MODULE SW9001



MULTIPLEXER MODULE SW9002



81 Koizumi. Ueda, Nagano 386-1192 Japan https://www.hioki.com/



regional contact information

All information correct as of Nov. 11, 2019. All specifications are subject to change without notice.

85452 Moosinning